## RD9

## TinySwitch<sup>™</sup>

# Flyback Prototyping Board

## **User Configurable Input and Output Voltages**



#### **Product Highlights**

#### **Unpopulated Prototyping Board**

- Complete layout for construction of *TinySwitch* flyback supply
- Convenient prototyping area on secondary side of board
- Single-sided construction
- RD9 boards can be combined for rapid prototyping with RD8 (available separately)




Figure 1. RD9 Board Overall Physical Dimensions.

### **Description**

The RD9 is a special printed circuit board (Figure 1) designed for rapid prototyping of TinySwitch-based flyback power supplies in the 1-3 W range. Component positions and an optimized layout are provided for a complete single output power supply as shown in Figure 2. Component size and placement are identical to evaluation board RD8. The board is designed to accommodate a transformer using an EE16 core with a 10 pin bobbin (Ying Chin YC-1607 or equivalent\*). In addition to the power supply circuitry, the RD9 also provides a prototyping area on the secondary side of the board for circuitry such as additional outputs or voltage and current regulators. Some typical application circuits that can be constructed using the RD9 printed circuit board can be found in the TinySwitch and RD8 data sheets, and Design Ideas DI-4 through DI-8.

For extremely rapid prototyping, the RD8 TinySwitch evaluation board and the RD9 prototyping board are perforated between the primary and secondary circuit areas, so that the primary half of the RD8 can be separated and combined with the secondary half of the RD9.




Figure 2. PC Board Layout of the RD9.




Figure 3. Schematic Diagram of a Typical RD9 Circuit.

## **Using RD8 and RD9 Together**

A complete RD9 board is shown in Figure 4, and an RD8 board in Figure 5. To combine the secondary side of RD9 with the primary side of RD8, follow the instructions below:






Figure 4. RD9 Printed Circuit Board.

Figure 5. RD8 Printed Circuit Board.

• Break the RD9 board along the perforations to separate the primary and secondary halves. The secondary half of the board contains the prototyping area (Figure 6).




Figure 6. Prepared RD9 Board.

• Prepare the RD8 board by removing T1, C5, and U2. Set these aside for reuse. Break the board along the perforations to separate the primary and secondary circuitry. The board should then look as shown in Figure 7.




Figure 7. Prepared RD8 Board.

• Fit the primary half of RD8 and the secondary half of RD9 together, using T1, C5, and U2 removed from the RD8 board to bridge between the two board halves (Figure 8). A different transformer can be substituted for T1. Use the cores and bobbins suggested in the text for best mechanical fit.



Figure 8. Combined RD8 and RD9.



#### For the latest updates, visit our website: www.powerint.com

Power Integrations reserves the right to make changes to its products at any time to improve reliability or manufacturability. Power Integrations does not assume any liability arising from the use of any device or circuit described herein, nor does it convey any license under its patent rights or the rights of others.

PI Logo and TOPSwitch are registered trademarks of Power Integrations, Inc. ©Copyright 1998, Power Integrations, Inc. 477 N. Mathilda Avenue, Sunnyvale, CA 94086

#### WORLD HEADOUARTERS NORTH AMERICA - WEST

Power Integrations, Inc. 477 N. Mathilda Avenue Sunnyvale, CA 94086 USA +1•408•523•9200 Main:

Customer Service:

Phone: +1•408•523•9265  $+1 \cdot 408 \cdot 523 \cdot 9365$ Fax:

Power Integrations International Holdings, Inc. Rm# 402, Handuk Building, 649-4 Yeoksam-Dong, Kangnam-Gu, Seoul, Korea

Phone: +82 • 2 • 568 • 7520 +82•2•568•7474 Fax:

#### NORTH AMERICA - EAST & SOUTH AMERICA

Power Integrations, Inc. Eastern Area Sales Office 1343 Canton Road, Suite C1 Marietta, GA 30066 USA Phone: +1•770•424•5152

+1•770•424•6567

#### **JAPAN**

Fax:

Power Integrations, K.K. Keihin-Tatemono 1st Bldg. 12-20 Shin-Yokohama 2-Chome, Kohoku-ku, Yokohama-shi, Kanagawa 222, Japan Phone: +81•45•471•1021 +81•45•471•3717

#### EUROPE & AFRICA

Power Integrations (Europe) Ltd. Mountbatten House Fair Acres Windsor Berkshire SL4 4LE, United Kingdom

Phone: +44•1753•622•208 +44 • 1753 • 622 • 209 Fax:

#### **INDIA** (Technical Support)

Innovatech #1, 8th Main Road Vasanthnagar Bangalore 560052, India Phone: +91•80•226•6023 Fax: +91.80.228.2191

#### **TAIWAN**

Power Integrations International Holdings, Inc. 2F, #508, Chung Hsiao E. Rd., Sec. 5, Taipei 105, Taiwan

+886•2•2727•1221 Phone: Fax: +886•2•2727•1223

#### APPLICATIONS HOTLINE

World Wide +1•408•523•9260

#### APPLICATIONS FAX

+1•408•523•9361 World Wide

