



**115:**  
 vorhandenes Halter abbauen und mit Pos. 11 ersetzen.  
 die Schrauben anlösen/entfernen  
 (existing holder unfix and replace with Pos. 11,  
 the same screws use again)

Schraube/Screw 11



Pf 67.000 SL Filter/Filter / Filter Fan 30167-104 01-...		12 12(4x)
1 2 3 4 5 6(opt.) 7 8 9 10 11 12(4x) 13 14 15	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15